

FIG. 1




FIG. 2A




FIG. 2B




FIG. 2C




FIG. 3




FIG. 4




FIG. 5









FIG. 6

FIG. 7







**FIG. 9****FIG. 10**



**FIG. 11**



**FIG. 12**



**FIG. 13**







FIG. 14






FIGURE 16A




FIGURE 16B

09885002-062101

# "Own" Release




Figure 16C

0985002-062101

Mode Selection




Administrator  
Login  
Buildscripts  
Run Mode  
Schedule Mode  
Results Mode  
Interactive Mode  
Maintenance Mode  
Help Mode  
Service Step Mode  
Configure RCP to Access NTP  
Configure RCP for Audio Analysis

Select

FIG. 17A

+

FIG. 17B



+




FIG. 17C




FIG. 17D